



Custom Fifth Wheel Brackets Kits

- Cuts install time by up to 50%
- Reduces or eliminates drilling
- Provides a custom fit
- To be used in combination with 16104/16204 rails. No need for universal brackets and hardware
- Rail mounting hardware included

* While Supplies Last

Make/Model	Style	Years From	Years To	Bracket Kit#	Notes	Base Rails Needed	
						Carbide	Black
CHEVROLET/GMC							
1500/2500LD Silverado/Sierra	New Body Only	2007	2012	16412	No Drill	16204	16104
	Classic Body Only	1999	2007	16418	Drill	16204	16104
2500HD/3500 Silverado/Sierra	New & Classic Body	2011	2012	16413	No Drill	16204	16104
		2001	2010	16418	Drill	16204	16104
DODGE							
Ram 1500	Including Mega & Crew Cabs	2009	2010	16422	Drill	16204	16104
	Except Mega & Crew Cabs	2009	2009	16421*	Drill	16204	16104
	6' & 8' Beds, Mega Cab Only	2006	2008	16420	No Drill	16204	16104
	All, Except Mega Cab	2002	2008	16419	No Drill	16204	16104
Ram 2500 & 3500	6' & 8' Beds, Including Mega Cab & 3500 4x4 w/ Overload Springs	2003	2012	16420	No Drill	16204	16104
FORD							
F-150 & F-250LD	6' 5" & 8' Beds Only	2004	2012	16441	No Drill	16204	16104
	All	1997	2003	16437	No Drill	16204	16104
F-150 Heritage Edition	Heritage Edition Only	2004	2004	16437	No Drill	16204	16104
F-250 & F-350 Super Duty	All	2011	2012	16424	No Drill	16204	16104
		2005	2010	16448	Drill	16204	16104
		1999	2004	16443	Drill	16204	16104
F-450 Super Duty	All, Except Cab & Chassis	2011	2012	16424	No Drill	16204	16104
		2008	2010	16448	Drill	16204	16104
NISSAN							
Titan	All, Including King & Crew Cabs	2004	2012	16470	Drill	16204	16104
TOYOTA							
Tundra	6' 5" Bed Only. Will not fit Crew Max	2007	2012	16468	Drill	16204	16104
	Standard Cab, Long Box Only	2000	2006	16465	No Drill	16204	16104

Semi-Custom Fifth Wheel Bracket Kits

- To be used in combination with 16100/16200 Rails, Hardware, and Brackets for a semi-custom fit
- Drilling required

*Except 16300 & 16305. Includes all necessary mounting hardware. Use with 16104 or 16204 rails.

Make/Model	Style	Years From	Years To	Bracket Kit#	Notes	Base Rails Needed	
						Carbide	Black
DODGE							
Ram 1500	Including Mega Cab	2009	2012	16305*	Drill	16204	16104
	With or Without Overload Springs	2002	2008	16303	Drill	16200	16100
Ram 2500 & 3500	With or Without Overload Springs	2003	2012	16301	Drill	16200	16100
FORD							
F-150	All, Except Heritage Edition	2004	2011	16300*	Drill	16204	16104
TOYOTA							
Tundra	6' 5" & 8' Beds. Will not fit Crew Max	2007	2008	16304	Drill	16200	16100
	Standard Cab, Long Box Only	2000	2006	16302	Drill	16200	16100

Universal Fifth Wheel Base Rails

Part #	Description	Finish
16100	2 Universal Fifth Wheel Base Rails (Includes Rails, Brackets, and Hardware)	Gloss Black
16104	2 Universal Fifth Wheel Base Rails Only (Brackets & Hardware Kit not included)	Gloss Black
16200	2 Universal Fifth Wheel Base Rails (Includes Rails, Brackets, and Hardware)	Carbide Black
16204	2 Universal Fifth Wheel Base Rails Only (Brackets & Hardware Kit not included)	Carbide Black
16101	Universal Fifth Wheel Rail Mounting Kit. Universal brackets and hardware included	