

OEM Replacement Harness Application Guide

Make/Model	Style	Years	Wiring Location
Buick			
Enclave		08-10	S5
Ranier		04-07	S5
Cadillac			
Escalade	Including Hybrid	02-10	S5
Escalade ESV		03-10	S5
Escalade EXT		02-10	S5
Chevrolet/GMC			
Acadia		09-10	S6
Avalanche		02-10	T3
Envoy		02-09	S5
Express/Savana		2009	T3
Silverado/Sierra	Classic & New Body Including Hybrid	99-11	T3
Suburban	Including Hybrid	00-10	S5
Tahoe	Including Hybrid	00-10	S5
Trailblazer		02-09	S5
Traverse		09-10	S5
Yukon	Including Hybrid	00-10	S5
Chrysler			
Aspen	Starting late built 2007 models	07-09	S5
Dodge			
Durango	Starting late built 2007 models	07-11	S5
Ram 1500		09-11	T3
Ram 2500/3500		10-11	T3
Ford			
Econoline Van		97-10	T3
Excursion		00-05	S5
Expedition		97-10	S5
Explorer		00-11	S5
Explorer Sport Trac		2009	S5
F-150		97-11	T3
F-250LD		97-99	T3
F-250 Super Duty		98-11	T3
F-350/F-450/F-550 Super Duty		99-11	T3
F-550 Super Duty		99-10	T3
Ranger		00-09	T3
Hummer			
H2		03-09	S5
H3		06-09	S5
H3T		2009	S5
Infiniti			
QX56		04-10	S5
Isuzu			
Ascender		03-08	S5
Lincoln			
Aviator		03-05	S5
Mark LT		06-08	T3
Navigator		98-10	S5
Mercury			
Mountaineer		02-10	S5
Nissan			
Armada		04-10	S6
Titan		04-10	T3
Oldsmobile			
Bravada		02-04	S5
Saab			
9-7X		05-09	S5
Saturn			
Outlook		07-09	S5
Toyota			

Tundra		10-11	T3
--------	--	-------	----