


GROSS LOAD CAPACITY WHEN USED AS A WEIGHT CARRYING HITCH: 5,000 LBS. TRAILER WEIGHT & 500 LBS. TONGUE WEIGHT.  
**\*\*\*DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY.\*\*\***

Parts List			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	1/2"	FISHWIRE TOOL
2	4	1/2-13 x 2 1/2 LG.	CARRIAGE BOLT
3	4	CM-SP12	.250 x 1.00 x 2.00" SQUARE HOLE SPACER
4	10	HFN 1213	HEX FLANGE NUT
5	6	1/2-13 x 1 1/4	HEX BOLT



HITCH WEIGHT: 32 LBS.

INSTALL TIME: 60 MINUTES

INSTALL NOTES:

- MAY REQUIRE CUTTING
- FISHWIRE

## INSTALLATION STEPS

- 1) Models with tow hooks must remove the factory bolt from the underside of the frame at the forward attachment point.
- 2) Fishwire the 1/2" carriage bolts and spacers through the frame as shown.
- 3) Fasten frame brackets to frame using 1/2" flange nuts. Ensure that the brackets are loosely installed to provide adjustment for future installation steps. Reinstall factory fasteners if removal was required.
- 4) Install cross member between brackets and secure with the hex bolts and flange nuts provided.
- 5) Tighten all bolts to proper torque specifications.

Note: Hitch can be installed in a "through bumper" or a "below bumper" configuration by reversing the cross member. Through bumper configuration requires a 3" square hole to be cut into the plastic fascia. Position the hole on the vehicle center line 3/12" below the top edge of the plastic fascia.

- 6) Torque 3/8" fasteners to 30 lb-ft.  
 Torque 7/16" fasteners to 54 lb-ft.  
 Torque 1/2" fasteners to 72 lb-ft.  
 Torque 5/8" fasteners to 150 lb-ft.

**PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE THAT ALL FASTENERS ARE TIGHT AND THAT ALL STRUCTURAL COMPONENTS ARE SOUND.**